

**5.56 mm AR 110C
SEMI AUTO RIFLE**

OPERATOR'S MANUAL



5.56 mm AR110C SEMI AUTO RIFLE

■ SPECIFICATIONS	7
A. Rifle	
B. Ammunition	
■ CHARACTERISTICS	7
■ HANDLING	8
A. Stock assembly	
B. Loading	
C. Use of selector lever	
D. Unloading	
E. Sight	
F. Sight zeroing	
G. Immediate action	
■ TROUBLE SHOOTING	17
■ STRIPPING	18
A. Magazine	
■ ORGANIZATIONAL MAINTENANCE MANUAL INCLUDING REPAIR PARTS AND BASIC ISSUE ITEMS LIST	25
A. Maintenance	
B. Lubrication	
■ ILLUSTRATED PARTS LIST	27
A. Upper receiver & Recoil spring group	
B. Bolt carrier group	
C. Lower receiver group	
D. Magazine group	
E. Cleaning Kit Group	
■ BASIC ISSUE ITEMS LIST	31
■ EXPLODED VIEW	31

OPERATOR'S MANUAL

ORGANIZATIONAL MAINTENANCE MANUAL INCLUDING REPAIR PARTS AND BASIC ISSUE ITEMS LIST



CONTENTS

FOREWORD 3

INTRODUCTION 6

SPECIFICATIONS 7

A. Rifle

B. Ammunition

CHARACTERISTICS 7

HANDLING 8

A. Stock assembly

B. Loading

C. Use of selector lever

D. Unloading

E. Sight adjustment

F. Sight zeroing

G. Immediate action

TROUBLE SHOOTING 17

STRIPPING 19

A. Magazine

B. Rifle

REASSEMBLY 28

CLEANING AND MAINTENANCE 28

A. Maintenance of the rifle

B. Lubrication

ILLUSTRATED PARTS LIST 27

A. Upper receiver & Recoil spring group

B. Bolt carrier group

C. Lower receiver group

D. Magazine group

E. Cleaning Kit Group

BASIC ISSUE ITEMS LIST 30

EXPLODED VIEW 31

FOREWORD

This manual is made for the information and guidance of personnel whose duties involve the use and maintenance of the 5.56mm AR110C and furthermore to enable him to use it with maximum efficiency.




Fig. 1 AR110C RIFLE (Butt Extended)




Fig. 2 AR110C RIFLE (Butt Retracted)

